X-ray Imaging Micro-Calorimeter Spectrometer

Piet de Korte

On behalf of an emerging calorimeter collaboration



Netherlands Organisation for Scientific Research

Contributors

GSFC(U.S)

Joe Adams, Simon Bandler, Regis Brekosky, Ari-David Brown, Jay Chervenak, Megan Eckart, Richard Kelley, Caroline Kilbourne, Scott Porter, Jack Sadleir, Steve Smith

ISAS (Japan) Kazu Mitsuda, Yoh Takei, Noriko Yamasaki

NIST(U.S)

Randy Doriese, Gene Hilton, Kent Irwin, Carl Reintsema, Joel Ullom, Leila Vale, *and others*!

PTB(Germany)

Joern Beyer, Dietmar Drung

SRON (Netherlands)

Marcel Bruijn, Bob Dirks, Luciano Gottardi, Henk Hoevers, Jan van der Kuur, Manuela Popescu, Marcel Ridder

VTT (Finland) Mikko Kiviranta

Mirror Driven Specifications

• Angular Resolution

5 arc sec resolution = 485 - 606 μm for 20 – 25 m focal length

Proposed Pixel size between 250 – 300 µm

• Field of View

7 arc min radius = 71 mm

• Countrate

1mCrab ~ 125 c/sec (May 2008, NASA IXO mirror concept with f = 20 m)



TES-based Micro-Calorimeter

SRON PIXEL DESIGN





TES-based Micro-Calorimeter

SRON ARRAYS



 5×5 array with Cu stems



5 x 5 array with Cu/Bi absorbers Close-up of 32 x 32 array

TES-based Micro-Calorimeter

PERFORMANCE for SRON PIXELS from 5 x 5 arrays $\Delta E_{TDI} \approx 3.1 \text{ eV } T_{C} = 105 \text{ mK}$



6

GSFC TES approach





Multiplexed TES calorimeter array



Also developed de-MUX software and we are now working on implementing real-time pulse height analysis



2 x 8 pixels read out with SQUID MUX



SAUGUST 20-22, 2008-

Facility Science Team - GSFC

IXO Meeting Munich 17 - 19 September 2008

FREQUENCY DOMAIN MULTIPLEXING CURRENT SUMMING TOPOLOGY



will 45



IXO Meeting Munich 17 - 19 September 2008

pixels/channel

BBFB electronics board realization





Amplitude and Phase measurements/model of BBFB On a commercial Xilinx breadboard



Amplitude: red-data blue-model Phase: red-data blue-model

Gain-bandwidth of 35 kHz for 200 kHz spacing and 830 ns delay

FLL-gain of 3.5x at highest signal frequency (10 kHz) and 22 x at 1.6 kHz (100 µs pulse decay time)

Focal Plane Array Layout (from Con-X \rightarrow IXO)

Central, core array:

- Individual TES one absorber/TES (40 x 40)
- 2 arcmin FOV
- 2.5 eV resolution (FWHM)
- Fast (< 300 μ sec time constant)

Outer, extended array

- 4 absorbers/TES
- Extends array to 52 x 52 pixels for a total of 2176 readout channels
- 5.0 arcmin FOV
- < 10 eV resolution</p>
- ~ 2 msec time constant



Multi Absorber TES - 1 TES, 4 absorbers

Simple approach: Separate absorbers (e.g., 4) connected to a single TES, each with a different thermal conductance.





Optimized high-speed array (GSFC)



High-speed calorimeter array

- 20 x 20 array of 1 arcsec pixels
- Distribute counts over ~ 10 times more pixels
- Use direct coupling to Si substrate for higher speed (~ 10's of micro-sec.)



ISAS/JAXA COOLING CHAIN

Cooler	1ST (100K)	2ST (20K)	2ST+ ⁴ He JT (4K)	2ST+ ³ He JT (2K)
Specification	2W@80K 50W, 4.2kg	325mW@20K 90W, 9.5kg	20mW @4.5K 120W, 23kg	16mW@1.7K 190W, 25kg
Ground test status	Life time test > 5 years (still running)	Life time test > 4 years (still running)	1 year test was done. A new lifetime test in preparation	Lifetime test in preparation
Mission status	Suzaku, in orbit 3.1 years	Akari, in orbit 2.5 years	FM for SMILES assembled	EM for SPICA & Astro-H(NeXT) assembled



Last stage cooler developments in Europe

Interface with satellite cryostat at 2.5 K with 10 mW cooling power

Options under development:

Closed d_{A} and 31 kg for 1 W during 30 hours



Cryostat design adopted for recent IDL study at GSFC





Si-doped X-ray Micro-calorimeter at CEA-Saclay

Herschel heritage: Developments by CEA-Saclay and LETI, Grenoble Contributed paper by Claude Pigot

Fully integrated sensor with read-out multiplexer





Results: - Impedance of 8X8 sensor matrix in the right range with good sensitivity

 Integration of absorber matrix onto sensor matrix promising
Next steps: April 2008: First 8X8 array with freed Sensor & Absorber End 2008: 1st Iteration Cold Electronics

Pro: Fully integrated system with multiplexed read-out Con: Till now no X-ray performance data, use of Ta-absorbers by other teams failed, potentially slow response, developments late for XEUS.

Focal Plane Array Layout for XEUS \rightarrow IXO



Central pixels: 1.37 x 1.37 arcmin 2.5 x 2.5 arcsec pixels 2 eV @ 2keV 100µs decay time

Field of View: 2.75 x 2.75 arcmin

Surrounding pixels: 5 x 5 arcsec pixels 4 eV @ 2 keV 400µs decay time

